



INSTALLATION INSTRUCTIONS
STILLEN FRONT & REAR SWAY BAR KIT
2005+ FORD MUSTANG
P/N 304100

Materials supplied:

1. (2) Sway Bar
2. (2)Rear upper bushings
3. (2) Rear lower bushings

Equipment needed:

1. Assorted sockets and wrenches



WARNING:

IF YOU ARE NOT EXPERIENCED IN THE AREA OF
AUTOMOTIVE MECHANICS WE STRONGLY URGE
THAT YOU REFER THIS INSTALLATION TO YOUR
MECHANIC.

Installation:

1. Raise the front of the vehicle and support with jack stands. Refer to the owners' manual for jack points. Use stops on the rear wheels to secure the vehicle.
2. You will be removing your stock front sway bar. It is bolted on the lower radiator support and the 2 end links coming off the struts. **(Fig.1)** Replace the bar with the supplied sway bar in the reverse operation. Once the install is complete you may lower the vehicle and move to the rear.
3. Raise the rear of the vehicle and support with jack stands. Refer to the owners' manual for jack points. Use stops on the front wheels to secure the vehicle
4. Next you will be removing the stock rear sway bar by unbolting it near the lower shock support on both sides as well as unbolting the links from the underbody. Remove the links from your stock bar and set them aside as they will be reused. **(Fig.2)**
5. Install the new bushings onto your new sway bar and install in the reverse operation as removed. Once the install is complete you may lower the vehicle.
6. Make a final pass on all the nuts to make sure everything is secure.
7. You are now done! Enjoy the enhanced handling of your New Stillen Sway Bar Kit !!

