



INSTALLATION INSTRUCTIONS
STILLEN FRONT SWAY BAR KIT
2005+ FORD MUSTANG
P/N 304101

Materials supplied:

1. (1) Sway Bar

Equipment needed:

1. Assorted sockets and wrenches



WARNING:

IF YOU ARE NOT EXPERIENCED IN THE AREA OF
AUTOMOTIVE MECHANICS WE STRONGLY URGE
THAT YOU REFER THIS INSTALLATION TO YOUR
MECHANIC.

Installation:

1. Raise the front of the vehicle and support with jack stands. Refer to the owners' manual for jack points. Use stops on the rear wheels to secure the vehicle.
2. You will be removing your stock front sway bar. It is bolted on the lower radiator support and the 2 end links coming off the struts. **(Fig.1)** Replace the bar with the supplied sway bar in the reverse operation. Once the install is complete you may lower the vehicle.
3. You are now done! Enjoy the enhanced handling of your New Stillem Sway Bar Kit !!

