



INSTALLATION INSTRUCTIONS
STILLEN STRUT TOWER BAR
08 NISSAN ALTIMA / 09 NISSAN MAXIMA
P/N 307024

Materials supplied:

1. (1) Strut bar assembly

Equipment needed:

1. Assorted sockets and wrenches



WARNING:

IF YOU ARE NOT EXPERIENCED IN THE AREA OF
AUTOMOTIVE MECHANICS WE STRONGLY URGE THAT
YOU REFER THIS INSTALLATION TO YOUR MECHANIC.

Installation:

1. First you will begin by removing the strut tower covers from the strut towers on the driver & passenger side. See **(Fig.1)**
2. You will be mounting the bracket to the location shown in **(Fig.2)** It is recommended that you loosen the bolt labeled A as well to help with installing the bracket, this bolt does not need to be completely removed but just enough to allow you to slide the bracket in place.
3. The finished installation should look as follows. **(Fig.3)** **Note: You will need to make cut out openings on the strut tower covers before reinstalling them onto the vehicle. See pg.2 (Fig.4)**
4. Done!!! Enjoy your new *STILLEN* strut tower bar.



